



	<b>Indice ricambi - Spare parts Italmacchine</b>			
	Molti altri ricambi disponibili su richiesta - Many other parts available on demand			
	Viele andere Ersatzteile auf anfrage - Autres pièces disponibles sur demande			
progr	Codice Originale	Codice Ebac	Description	
001	07.0711.9279	AFD1909	Asta sterzo completa - Tie rod bar assy	D
002	6194019	AFD1910	Asta sterzo completa - Tie rod bar assy	D
003	6193675	AFD1911	Asta sterzo completa - Tie rod bar assy	D
004	501548	AFD1912	Asta sterzo completa - Tie rod bar assy	D
005	501549	AFD1913	Asta sterzo completa - Tie rod bar assy	D
006	503467	SA57030	Snodo assiale - Axial joint	
007	501474	SA57031	Snodo assiale - Axial joint	
008	9398051	AFS3969	Disco freno - Friction disc	
009	1.526.9377	AFS4397	Disco freno - Friction disc	
010	1.527.1604	AFS4289	Disco freno - Friction disc	
011	1.527.2500	AFS4785	Disco freno - Friction disc	
012	1.527.2537	AFS4789	Disco freno - Friction disc	
013	1.550.2718	AFS6399	Disco freno - Friction disc	
014	7.126.479	AFS2719	Disco freno - Friction disc	
015	V007483	AFS5177	Disco freno - Friction disc	
016	V008887	AFS7215	Disco freno - Friction disc	
017	9398148	AFA3600	Disco freno intermedio - Steel friction disc	
018	1.527.1593	AFA4282	Disco freno intermedio - Steel friction disc	
019	1.527.1603	AFA4300	Disco freno intermedio - Steel friction disc	
020	1.527.2502	AFA4790	Disco freno intermedio - Steel friction disc	
021	1.550.1754	AFA6998	Disco freno intermedio - Steel friction disc	
022	V007484	AFA5180	Disco freno intermedio - Steel friction disc	
023	V008888	AFA7218	Disco freno intermedio - Steel friction disc	
024	630229	IM92203	Leva A-I - Fw-Rw lever	
025	638046	IM64083	Devio luci - Light device	
026	634649	IM94643	Quadro avviamento - Starting key	
027	639948	IM84993	Specchio retrovisore - Mirror	
028	635227	IM72253	Silentblock - Silentblock	
029	637356	IM65373	Serratura interna - Int. Lock door	
030	637657	IM75673	Maniglia est. - Ext handle	
031	639146	IM64193	Leva vetro - Glass lock lever	
032	631177	IM77113	Faro rotante - Warning light	
033	630153	IM35103	Fanale posteriore - Rear light	
034	636208	IM80263	Fanale ant. direzione - Front light steer	
035	636205	IM50263	Fanale lat. Freccia - Lat.light steer	
036	636207	IM70263	Fanale anteriore - Front light	
037	626145	IM54162	Crociera trasmiss. - Transmission cross	
038	908560	IM06580	Sensore - Warning	
039	625246	IM64252	Cuscinetto rullo botte - Drum roller bearing	
040	633001	IM10033	Silentblock - Silentblock	
041	635033	IM33053	Kit giunto pompa trazione - Hydr. pump coupling	
042	629540	IM04592	Cavo acceleratore - Accelerator cable	p-p
043	636862	IM26863	Pompa freno pedale - Brake pump pedal	
044	636668	IM86663	Accumulatore - Brake buster	
045	634740	IM04743	Leva freno - Brake lever	
046	634748	IM84743	Filo freno a mano - Hand brake cable	
047	631676	IM67613	Motore rotaz. Botte - Hydr. motor drum	
048	635743	IM34753	Pompa rotaz. Botte - Hydr pump drum	
049	627882	IM28872	Cartuccia olio - Hydr oil cartridge	
050	635742	IM24753	Pompa trazione - Transm. Hydr pump	
051	635972	IM27953	Motore trazione - Transm. Hydr motor	

	<b>Indice ricambi - Spare parts Italmacchine</b>		
	Molti altri ricambi disponibili su richiesta - Many other parts available on demand		
	Viele andere Ersatzteile auf anfrage - Autres pièces disponibles sur demande		
progr	Codice Originale	Codice Ebac	Description
052	626624	IM42662	Motore pompa acqua - Hydr motor water pump
053	626219	IM91262	Pompa acqua - Water pump
054	322960	IM06922	Contaltri acqua - Water meter
055	633020	IM02033	Disco freno interm. - Steel Friction disc H1
056	633019	IM91033	Disco freno - Friction disc H1
057	634733	IM33743	Asta sterzo completa - Tie rod bar assy D
058	09.4610.0004	IM400164	Sedile - Seat
059	07.0723.0024	IM423270	Specchio retro - Mirror
060	09.4610.0011	IM110164	Molla a gas - Spring cylinder
061	54.0702.0000	IM002070	Pattino braccio - Boom Pad
062	54.0702.0001	IM102070	Pattino braccio - Boom Pad
063	54.0702.0013	IM312070	Pattino braccio - Boom Pad
064	07.0711.0016	IMC611170	Rondella - washer
065	07.0711.0243	IMC341170	Boccola - Bush
066	07.0711.0019	IMC911170	Boccola - Bush
067	07.0711.0201	IMC101170	Paraolio - Oil seal
068	07.0711.0038	IMC831170	Snodo assiale - Axial joint
069	07.0711.0037	IMC731170	Asta sterzo completa - Tie rod bar assy D
070	07.0711.0040	IMC041170	Tirante sterzo - Tie rod end
071	07.0711.0219	IMC912117	Kit guarnizioni - Gasket kit
072	07.0711.0046	IMC641170	Boccola - Bush
073	07.0711.0214	IMC 412117	Paraolio - Oil seal
074	07.0711.0121	IMC121117	Coppia conica - Bevel pinion & crown gear
075	07.0711.0060	IMC601170	Cuscinetto - Bearing
076	633805	IMC50833	Disco bloccaggio - Diff. Plate block
077	633806	IMC60833	Disco bloccaggio - Diff. Plate block
078	633807	IMC70833	Disco bloccaggio - Diff. Plate block
079	07.0711.0129	IMC921117	Semiasse - Axle shaft
080	07.0711.0086	IMC681170	Crociera semiasse - Axle shaft cross
081	07.0711.0203	IMC302117	Paraolio - Oil seal
082	07.0711.0103	IMC301117	Anello - Ring
083	07.0711.0220	IMC022117	Rondella - washer
084	07.0711.0102	IMC201117	Rondella - washer
085	07.0711.0139	IMC931117	Kit registro - Self adjust. Kit
086	07.0711.0003	IMC301170	Disco guida - Drive plate
087	07.0711.0004	IMC401170	Disco freno - Friction disc
088	07.0711.0005	IMC501170	Disco freno interm. - Steel Friction disc
089	07.0711.0006	IMC600117	Disco guida - Drive plate
090	07.0711.0141	IMC141117	Ingranaggio Z60 - Gear
091	07.0711.0240	IMC042117	Treno planetari - Planetary carrier
092	07.0711.0221	IMC122117	Ingranaggio sat - Gear
093	07.0711.0222	IMC222117	Kit rullini - Roller bearing kit
094	07.0711.0110	IMC011117	Rasamento - Thrust washer
095	07.0711.0187	IMC781117	Disco freno a mano - Hand brake disc
096	07.0711.0188	IMC881117	Attuatore - Actuator
097	07.0711.0082	IMC281170	Semiasse - Axle shaft SX / LH
098	07.0711.0083	IMC381170	Semiasse - Axle shaft DX / RH
099	07.0711.0108	IMC801117	Treno planetari - Planetary carrier
100	07.0711.0216	IMC612117	Ingranaggio sat - Gear
101	07.0711.0111	IMC111117	Corona epic. - Crown gear
102	07.0711.0094	IMC491170	Ingranaggio epic - Gear







Ebac code			Description
BBV2720.901			Brake master cylinder




Ebac code			Description
BBV2720.812			Brake master cylinder




Ebac code			Description
BBV3025.908			Brake master cylinder



Ebac code			Description
BSF1944.04			Brake master cylinder




Ebac code			Description
BSF2648.12			Brake master cylinder




Ebac code			Description
BSF215 P			Pedal Brake master cylinder


RICAMBI <b>EBAC</b>	Ricambi Italmacchine - Terex IM	Spare parts Italmacchine
------------------------	---------------------------------	--------------------------



Ebac code			Description
AC0010	FNR - SF - Light		Handler device




Ebac code			Description
AC0011	FNR - I-II Speed - Light		Handler device




Ebac code			Description
AC0013	FNR		Handler device
AC0014	Light - Wiper		Handler device


RICAMBI <b>EBAC</b>	Ricambi Italmacchine - Terex IM	Spare parts Italmacchine
------------------------	---------------------------------	--------------------------



Ebac code			Description
AD0005	Dx - Rh		Front light
AD0006	Sx - Lh		Front light



Ebac code			Description
AD2001	Dx - Rh		Direction light
AD2002	Sx - Lh		Direction light



Ebac code			Description
AD3001	Dx - Rh		Rear light
AD3002	Sx - Lh		Rear light